



Anziehvorschrift für Zylinderkopf	151.262	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
	passend für / suitable for adaptable à / adaptable a	Porsche

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



Anziehen/ 15 Nm
Tightening/ 30 Nm
Serrage/ 360°
Apriete 20 Nm
 20 Nm
 120° +/- 2°

Zeichenerklärung / Explanations / Explication / Explicacion

* ✱	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

3,6l B6 Turbo Ø: 101,7mm ±: 0,60mm

Mot: M97.70, M97.70S, M97.76
305-390KW (415-530PS)

Porsche 911 (997)

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

151.262