



Anziehvorschrift für Zylinderkopf	308.102	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
passend für / suitable for adaptable à / adaptable a		Porsche

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



872.290
M 12x1,5x140

Anziehen/ Tightening/ Serrage/ Apriete	* 5 Nm	M6x25: 13 Nm
	□ 50 Nm	
	□ lösen / loosen 4 Nm	
	12 Nm	
	➤ Pos. 1-4: 65°	
	➤ Pos. 5-8: 60°	
	➤ Pos. 1-4: 65°	
	➤ Pos. 5-8: 60°	

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

6-Cyl. 3,0l 24V Boxer Cyl. 4-6
Ø: 93mm ⚙: 0,62mm

MDC.HA MDC.JA MDC.KA

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

308.102