

FITTING INSTRUCTIONS
 EINBAUANLEITUNG
 INSTRUCCIONES DE MONTAJE
 NOTICE DE MONTAGE
 ISTRUZIONI DI MONTAGGIO
 INSTRUKCJA MONTAŻU
 INSTRUÇÕES DE MONTAGEM
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir®

Ford C	Max	09.10 ->	80001772
Ford Focus	III	03.11 ->	CP1432
Ford Grand	C Max	09.10 ->	MP398
Ford Kuga	II	02.13 ->	80001773
Volvo V40	II	06.12 ->	CC1432
			MC898
			49408564
			CB1432
			BL898

