

FITTING INSTRUCTIONS
 EINBAUANLEITUNG
 INSTRUCCIONES DE MONTAJE
 NOTICE DE MONTAGE
 ISTRUZIONI DI MONTAGGIO
 INSTRUKCJA MONTAŻU
 INSTRUÇÕES DE MONTAGEM
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir®

Audi	A3	08.12 ->	80004514
Audi	Q2	07.16 ->	CP1455
Audi	TT	03.14 ->	MP437
Audi	TTS	03.14 ->	
Seat	Ateca	06.16 ->	80004514
Seat	Leon III	12.12 ->	CC1455
Skoda	Karoq	10.17 ->	MC937
Skoda	Kodiaq	10.16 ->	
Skoda	Octavia III	01.13 ->	49408486
Skoda	Superb III	05.15 ->	CB1455
Volkswagen	Arteon	04.17 ->	BL937
Volkswagen	Golf Sportsvan	04.14 ->	
Volkswagen	Golf VII	12.12 ->	
Volkswagen	Passat	11.14 ->	
Volkswagen	Tiguan	01.16 ->	
Volkswagen	Touran	05.15 ->	
Volkswagen	T-Roc	07.17 ->	

