

FITTING INSTRUCTIONS  
 EINBAUANLEITUNG  
 INSTRUCCIONES DE MONTAJE  
 NOTICE DE MONTAGE  
 ISTRUZIONI DI MONTAGGIO  
 INSTRUKCJA MONTAŻU  
 INSTRUÇÕES DE MONTAGEM  
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

**micronAir®**

Citroën  
 Peugeot  
 Fiat

Jumper  
 Boxer  
 Ducato

07.06 ->  
 07.06 ->  
 01.07 ->

80000815  
 CP1278  
 MP262

80000816  
 CC1278  
 MC762

CB1278  
 BL762

