

FITTING INSTRUCTIONS
 EINBAUANLEITUNG
 INSTRUCCIONES DE MONTAJE
 NOTICE DE MONTAGE
 ISTRUZIONI DI MONTAGGIO
 INSTRUKCJA MONTAŻU
 INSTRUÇÕES DE MONTAGEM
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir®

Audi				
A1	GBA	07.18 ->	49428077	
Seat			CP1549	
Arona	(KJ)	09.17 ->	MP 493	
Ibiza VI	(KJ)	06.17 ->		
Skoda			49402330	
Scala		02.19 ->	CC1549	
Kamiq		04.19 ->	MC 993	
Volkswagen			49455814	
T-cross		12.18 ->	CB1549	
Polo VI	(AW)	07.17 ->	BL993	

