

FITTING INSTRUCTIONS
 EINBAUANLEITUNG
 INSTRUCCIONES DE MONTAJE
 NOTICE DE MONTAGE
 ISTRUZIONI DI MONTAGGIO
 INSTRUKCJA MONTAŻU
 INSTRUÇÕES DE MONTAGEM
 ИНСТРУКЦИЯ ПО УСТАНОВКЕ

micronAir®

Opel	ATS	02.13 ->	49365684
Cadillac	CTS	09.13 ->	CP1526
Cadillac	Ampera-E (F17)	05.17 ->	MP470
Opel	Astra (K)	08.15 ->	
Opel	Meriva	07.12 ->	49365685
Opel	Insignia (B)	03.17 ->	CC1526
			MC970

