



## Einbauhinweis/installation instruction VW Passat B6 2006 - 2011

Vorne rechts/Front right (OE Ref. No. 3C1 837 462F)

