



<b>Anziehvorschrift für Zylinderkopf</b>	<b>182.790</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



Anziehen/	*	29 Nm
Tightening/		69 Nm
Serrage/	<input type="checkbox"/>	1 - 2: 34 Nm
Apriete	<input type="checkbox"/>	3 - 6: 15 Nm
	➤	1 - 6: 90°
	➤	1 - 6: 90°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
<input type="checkbox"/>	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Durchm. 89,0 mm  
Mot. EJ16 1,6i 4WD 1597 ccm SOHC 16V  
Impreza GC, GF 1992-  
Mot. EJ18 1,8i 4WD 1820 ccm SOHC 16V  
Legacy BC, BJT 1989-      Impreza GC, GF 1992-

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*182.790\***