



<b>Anziehvorschrift für Zylinderkopf</b>	<b>540.480</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
	passend für / suitable for adaptable à / adaptable a	<b>Nissan</b>

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



Anziehen/ \* 29 Nm  
Tightening/ 78 Nm  
Serrage/ □ -360°  
Apriete ▶ 29 Nm  
80°-85°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
▶	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

MC KA24E  
Nissan Pick up 2,4i 12V 04.92-02.98 91KW  
Nissan Pick up 2,4i 02.98- 88KW  
Nissan Prairie 2,4i 04.92-07.94 98KW  
Nissan Terrano II 2,4 ltr. 05.96-01.02 85KW  
Nissan Terrano II 2,4i 12V 02.93-06.96 91KW  
Ford Maverick 2,4i 02.93-08.96 91KW

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*540.480\***