NEW PRODUCT HIGHLIGHT | JAN2020



Blue Print ADC46827

to fit:

Mitsubishi L200, L300



FUEL FILTER PRIMING PUMP

Function

The diaphragm type priming pump, is installed on the top of the fuel filter. This is used during the air bleeding procedure and is carried out after replacing the fuel filter, once the fuel system has been repaired or when the vehicle is refilled with fuel after running out.

Cause of Failure

The diaphragm deteriorates with time, becoming weak or it can perforate letting air into the fuel system. This leads to poor engine starting and makes it difficult to bleed the fuel system; this is usually discovered after replacing the fuel filter.