



## Note !

## **Spring Shims**

Rubber shims, fitted at the uppermost spring end, allow for fine adjustment of the vehicle rideheight and are available in four different thicknesses. Shim thickness can be easily determined by counting the number of "pips" on the shim lip, e.g. 1 pip (5 mm), 2 pips (9 mm), 3 pips (13 mm) and 4 pips (17 mm). Check the condition of the rubber shim during spring replacement and if damaged, replace with a new shim to guarantee correct ride-height.

Replacement shims are listed separately in the SUPLEX Spring Seat Catalogue.

Vehicle ride height on the rear-axle can be fine tuned by fitting a thinner or thicker spring shim.

19391 : 1x violet 19392 : 2x violet

19429: 3x violet


